


Coil Cord Output Positions

Top View of Coil



V109 V102	V101 V103 V106 V113	V112	V103 V103H V104H	V101 V104 V106 V114	V113S
--------------	------------------------------	------	------------------------	------------------------------	-------

- * V101, V106 - Can be placed in either D or A
- ** V113S Is a double slotted angle mount
- *** V103 - Can be placed in either D or B